



TJERNLUND PRODUCTS, INC.

1601 Ninth Street • White Bear Lake, MN 55110-6794
PHONE (800) 255-4208 • (651) 426-2993 • FAX (651) 426-9547
Visit our web site • www.tjernlund.com

MODEL (950-0018) SS2 REPLACEMENT HIGH LIMIT INSTRUCTIONS

READ INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION

WARNING

Disconnect power supply before making wiring connections to prevent electrical shock and equipment damage.

NOTE: The High Limit Switch you are replacing may not be defective. Depress reset button on High Limit as noted in troubleshooting guide in the SS2 instructions or junction box label on back of SS2. Call us toll free at 1-800-255-4208 if you are unsure if the High Limit is defective.

1. Remove vent pipe and SS2 inlet pipe by twisting counter clockwise.
2. Remove (9) screws from rear and bottom of vent cabinet.
3. Remove electrical conduit from SS2 electrical box. Slide venter assembly out of SS2 cabinet and set assembly on its side on a flat working surface.
4. Remove (2) wires and (2) screws from High Limit Switch.
5. Remove defective High Limit Switch from SS2.
6. Follow the above steps in reverse order for reassembly of new High Limit Switch and SS2.
7. Reestablish power and run SS2 & appliance through a couple of heating cycles to verify proper operation.

